













Original instructions

## PA2DR




# PA2DR



Funktion/ Function/ Function/ Funktionsweise/ Принцип действия/ Fonction/ Funcionamiento/ Sposób działania/ Function


(A)

Exempel/  
Examples/  
Eksempel/  
Beispiele/  
Примеры/  
Exemples/  
Ejemplo/  
Voorbeelden/  
Przykładowe/  
Esempio



(B)

Exempel/  
Examples/  
Eksempel/  
Beispiele/  
Примеры/  
Exemples/  
Ejemplo/  
Voorbeelden/  
Przykładowe/  
Esempio



\*Under tiden dörren är öppen ökar börvärdet automatiskt med 2 °C. / While the door is open the set point will automatically increase with 2 °C. / Når døren er åpen vil effekten automatisk øke med 2 °C. / Wenn die Tür geöffnet ist, steigt der Sollwert automatisch um 2 °C. / При открытом проеме заданная температура автоматически повышается на 2 градуса. / Le point de consigne passe automatiquement à 2 °C dès lors que la porte est ouverte. / Mientras la puerta esté abierta, el valor de ajuste aumentará automáticamente 2 °C. / Als de deur open is, neemt het instelpunt automatisch met 2 °C toe. / Przy otwartych drzwiach warto zadana automatycznie wzrasta o 2°C. / Quando la porta è aperta il valore di setpoint aumenta automaticamente con 2 °C.

**Main office**

Frico AB  
Box 102  
SE-433 22 Partille  
Sweden

Tel: +46 31 336 86 00  
Fax: +46 31 26 28 25  
mailbox@frico.se  
www.frico.se

**For latest updated information and information  
about your local contact: [www.frico.se](http://www.frico.se)**